

Engineered Wood Products available in Ontario

March 2011

Type	Manufacturer	Product Name	Available Depths										Documentation (PDF)	
			3 ½"	5 ½" - 5 ¾"	7 - 7 ¼"	9 ¼" - 9 ½"	11 ¼" - 11 ¾"	14"	16"	18"	20"	22" - 24"		
I-Joist	Alpa Floor System	QFS A310E, A312E, A314E, B310E B312E, B314E				X	X	X						Canadian Specifier Guide
	Anthony Domtar	ADI-40, ADI-60, ADI-80		X	X	X	X	X	X	X	X			Power Joist User Guide - Canada
	Boise Cascade	AJS 140, 20, 25				X	X	X	X					ALJOIST Specifier Guide - Canada
	iLevel by Weyerhaeuser	TJI S31, S33, S47				X	X	X	X	X	X			#TJ-4510 Specifier's Guide - Canada
	International Beam	IB 400, 600, 800				X	X	X	X					Residential Design Manual - Canada
	Louisiana Pacific	LPI 20+, 32+, 42+				X	X	X	X					LP SolidStart LPI 20-32-42Plus Tech Guide - Canada
	Nascor	NJ, NJH, NIJ				X	X	X	X	X				Canadian Specifier Guide
	Nordic Engineered Wood	NI 20, 40X, 60, 80 NI 60, 80x				X	X	X	X			X	X	Residential Design/Construction Guide - Canada Light Commercial I-Joists - Canada
	Distribution Toiture Mauricienne	OpenJoist 2000				X	X	X	X					Load Charts - Canada
Floor Truss	Ontario Wood Truss Fabricators Association (OWTFA)	n/a	Custom										Truss Design Procedures & Specs - TPIC20007	
Beams	Boise Cascade	Versa-Lam 2.0E			X	X	X	X	X	X	X			VERSA-LAM Specifier Guide - Canada
	iLevel by Weyerhaeuser	Microllam LVL 1.9E		X	X	X	X	X	X	X	X	X		#TJ-9500 Specifier's Guide - Canada
		Parallam PSL 2.0E		X	X	X	X	X	X	X	X			#TJ-9500 Specifier's Guide - Canada
	Louisiana Pacific	LP SolidStart LVL 1.9E, 2.0E			X	X	X	X	X	X	X	X	X	LP SolidStart LVL 2250-2400-2650-2950 - Canada
	West Fraser	West Fraser LVL 2.0E		X	X	X	X	X	X	X	X	X	X	LVL User's Guide - Canada
Studs	Boise Cascade	Versa-Lam 1.7E	X	X	X									VERSA-LAM Specifier Guide - Canada
	iLevel by Weyerhaeuser	TimberStrand LSL 1.3E, 1.5E	X	X	X									#TJ-9503 Specifier's Guide - Canada
	Louisiana Pacific	LP SolidStart LVL 1.5E	X	X										Canadian Literature is pending
Columns	Boise Cascade	Versa-Lam 1.7E	X	X	X									VERSA-LAM Specifier Guide - Canada
	iLevel by Weyerhaeuser	Parallam PSL 1.8E	X	X	X									#TJ-9500 Specifier's Guide - Canada
		TimberStrand LSL 1.3E, 1.55E	X	X	X									
	West Fraser	West Fraser LVL 1.8E	X	X	X									LVL User's Guide - Canada
Glulam	Goodfellow	GoodLam	Custom depths (typically in intervals of 1 ½" or 38mm)										Goodlam Product Guide - Canada	
	Nordic Engineered Wood	Nordic Lam											Nordic Lam Design/Construction Guide - Canada	
	Structurlam	Glulam											Contact Structurlam	
	Western Archrib	WestLam											Product Specs	
Roof Truss	Ontario Wood Truss Fabricators Association (OWTFA)	n/a	Custom										Truss Design Procedures & Specs - TPIC20007	

Other products, depths, strengths and series may be available through custom order - contact the manufacturer for further information.